











Pick the right satellite antenna for you.

	MODEL	TVS	SATELLITE COVERAGE	TYPE	
	DISH Playmaker®	 One TV Option	Western 110°, 119°, 129° and Eastern 61.5°	Portable (optional roof mount kit)	Shop Now
	DISH Playmaker Dual®	 Two TV Option	Western 110°, 119°, 129° and Eastern 61.5°	Portable (optional roof mount kit)	Shop Now
	DISH Tailgater®	 One TV Option	Western 110°, 119°, 129° and Eastern 61.5°	Portable/ Mountable	Shop Now
	DISH Tailgater Pro®	 Two TV Option	Western 110°, 119°, 129° and Eastern 61.5°	Portable/ Mountable	Shop Now
	Trav'ler®	 Three TV Option	Western 110°, 119°, 129°	Mounted	

All antennas automatically locate DISH satellites and are capable of picking up both HD and SD channels.